


PLEASE READ CAREFULLY

PARTS GUIDE

FIRING CAN




CHAMBER GUIDE



PLEASE READ CAREFULLY

PARTS GUIDE


MAIN CHAMBER



PARTS GUIDE

PLEASE READ CAREFULLY


BOLT



PLEASE READ CAREFULLY

PARTS GUIDE


SOLENOID VALVE MANIFOLD



PARTS GUIDE

PLEASE READ CAREFULLY


BOLT CONTROL MANIFOLD



PLEASE READ CAREFULLY

PARTS GUIDE


LATCH ASSEMBLY



PARTS GUIDE

PLEASE READ CAREFULLY


VISION™ COVER




PLEASE READ CAREFULLY

PARTS GUIDE

CLAMPING FEEDNECK




REGULATOR SPRING GUIDE




PLEASE READ CAREFULLY

PARTS GUIDE

REGULATOR PISTON



REGULATOR BASE



PLEASE READ CAREFULLY

PARTS GUIDE


SPRING PLATFORM BASE



PARTS GUIDE

PLEASE READ CAREFULLY






REGULATOR SPRINGS



PLEASE READ CAREFULLY

PARTS GUIDE


BODY SCREWS



PARTS GUIDE

PLEASE READ CAREFULLY

BOTTOM LINE ASA



SHK206
BOTTOM OF FRAME


FLT004




OM9007



SSC010 (2)
BLUE LOCTITE 242



SHK237



SHK236




SHK138

OU9005
APPLY GR33SE™

PLEASE READ CAREFULLY

PARTS GUIDE

TRIGGER



PARTS GUIDE

PLEASE READ CAREFULLY

GRIP FRAME

